



Institute of Refractories Engineers

Thermal Expansion

Training Day 2016

M Frith
Sheffield
13 October 2016




Contents

- Introduction
- What is Thermal Expansion?
- Methods of Dealing with Thermal Expansion in Refractory Constructions
- Thermal Stress
- Examples




What is Thermal Expansion? The Science bit

- Thermal expansion is the tendency of matter to change in shape, area and volume in response to a change in temperature through heat transfer.
- Temperature is a function of the average molecular kinetic energy of a substance.
- When a substance is heated, the kinetic energy of its molecules increases. The molecules move more and usually maintain a greater average separation.



Thermal Expansion of Standard Refractory Materials





Thermal Expansion Coefficient

- A Material Property – independent of shape
- $cte = \frac{\Delta L}{L} \cdot \frac{1}{\Delta T}$
- ΔL is change in length (expansion)
- ΔT is temp change
- $\Delta L = cte \cdot L \cdot \Delta T$

The **coefficient of thermal expansion (cte)** describes how the size of an object changes with a change in temperature. Specifically, it measures the fractional change in size per degree change in temperature at a constant pressure.



Forces Involved in Thermal Expansion

- Construction:
 - Refractory lined duct 10m long, 2m in diameter
 - Lined with 230mm thick fireclay brick
 - Taken to a temperature of 1000°C.
 - Elastic Modulus is ~ 20 GPa.
- The resultant thermal expansion is 55mm.

Restraining force for zero movement – 28,000tonnes



Methods of Dealing with Thermal Expansion: Golden Rule

If the unstoppable force meets the immovable object, something gets broken.

- Splitting of shell
- Weld failure
- Flange bolts stretch
- Shell Yields
- Insulation crushed
- Lining spalls


It is therefore essential to make a suitable allowance for thermal expansion in any design.

Several methods are commonly used.



Methods of Dealing with Thermal Expansion Method 1: FREE MOVEMENT

- Rarely used
- Movement is not predictable
- Applied to free- standing, unconstrained structures only
 - Beehive Kilns
 - Bottle Kilns






Methods of Dealing with Thermal Expansion

Method 2: Regular Gaps


- Leave gaps of pre-determined size
- These close up on heating
- Few, large gaps – typically 50mm
- What can go wrong?
- What happens at branches?



Methods of Dealing with Thermal Expansion

Method 3: Burn-Out Packs

- Smaller gaps, placed more frequently and at regular intervals
- Less risk of slipping
- Less risk of problems from non-closure
- What can go wrong?





Methods of Dealing with Thermal Expansion

Method 4: Compressible Layer

- Layer can be behind hot face in joints/gaps
 - Can eliminate gaps in hot face
- Range of compressible materials
- Compression is PLASTIC

- What can go wrong?




Methods of Dealing with Thermal Expansion

Method 5: Adjust Casing

- Only used in special cases
- Needs adjustment during warm up
- Needs adjustment during cool down
- Retains arch SHAPE

- What can go wrong?





Methods of Dealing with Thermal Expansion Method 6: No Specific Allowance

- Mortar Creep
- Shell is hot and therefore expands
- Stress is developed in shell
- Used in rotary kilns



- What can go wrong?



Methods of Dealing with Thermal Expansion Methods in Combination

Often use different methods in combination
e.g. Hot Blast Vertical Riser Pot

- Walls – Radial expansion – Combustible Packs
- Walls – Vertical Expansion – Free growth
- Dome – Radial Expansion – No allowance
- Dome – Vertical Expansion – compressible layer





Thermal Stress

The contraction and expansion process of a material with temperature can result in thermal stress if:

- There is interference from contacting another part,
- If the construction is made out of different types of materials that have different thermal expansion coefficients.
- e.g. Expansion of anchors can cause anchor to cracking
 - $\text{cte } 310 = 18 \times 10^{-6}/^{\circ}\text{C}$
 - $\text{cte } 1600 \text{ castable} \approx 6 \times 10^{-6}/^{\circ}\text{C}$
 - Anchor temp is higher than refractory temp



Thermal Stress: A few Key Points

- Steel usually expands less than refractory (depends on thermal design)
 - Leads to the development of compressive and tensile thermal stress in the refractory lining
- No such thing as a 'flexible' refractory
 - Flexible products harden on heating
 - Compressible NOT elastic
 - Compressible refractory has little mechanical resistance
- Expansion Joints in steel
 - Often cause problems
 - Sliding joints are hard for refractories



Thermal Stress: Analysis


- The level of thermal stress development in a refractory structure can be calculated via Finite Element Method (FEM) analysis
- This requires knowledge of the thermo-mechanical properties of the materials and the constructional aspects of the lining/container
- Thermo-mechanical properties:
 - Thermal expansion coefficient
 - Thermal conductivity
 - Modulus of elasticity
 - Failure stress and Failure strain
 - ETC.....



Thermal Stress: FEM Analysis REHEAT FURNACE ROOF





- Furnace cycled between 1300c and 900c every 12 hours
- Furnace switched off every Friday, and relit prior to rolling Monday
- Fast cool down the rate
- Fast heat up rate
- Areas of premature wear/failure
 - Block anchors in the roof witnesses as splitting
 - Block anchors in the Discharge sloping roof
 - Bull nose sloping roof slippage






Thermal Stress: FEM Analysis REHEAT FURNACE ROOF




Thermal Calculations



Ceramic anchor block
Cools more rapidly than
the roof block


Mechanical Calculations



Tensile stress generation
at the transition zone of
the ceramic anchor – leads
to cracking of block and
loss of the front face



Finite Element Method Thermal Stress Analysis – BOS Converter





Incorrect Expansion Allowance 'when we get it wrong! - Examples



Thermal Expansion of railroad track due to excessive heating. Yes, they would close the track at this point! (Notice the derailed car in the background.)



Incorrect Expansion Allowance 'when we get it wrong! - Examples




(C) 2007 Daniel Friedman - inspect-ny.com





(C) 2007 Daniel Friedman - inspect-ny.com



Incorrect Expansion Allowance 'when we get it wrong! - Examples



Incorrect Expansion Allowance 'when we get it wrong! - Examples





Thank you for your attention